



U.S. Patent No. 6,047,490 • Patents Pending

*Fire Cartridges with your Cap & Ball revolver*

## **Installing Ejector Systems**

### **1851 Colt Improved Ejector**

Remove the loading lever screw and the loading lever.

Back out the barrel wedge. Remove the screw and the nut from the ejector.

Hold the ejector sideways and replace the nut, (with the thicker edge towards the muzzle).

Hold revolver sideways; slide assembly straight up into place.

Hold in place with thumb, turn over and insert screw.

Reinstall the barrel wedge.

### **1860/61 Colt Ejector**

Remove the loading lever screw and loading lever.

Back the barrel wedge out and slide the ejector assembly into the loading lever slot.

Insert ram plug with the angled end out; line up angled end of plug with the ejector bracket. Tighten set screw.

Some filing for a finer fit may be required.

### **1858 Remington Ejector**

Remove the loading lever screw

Remove the Loading Lever and Cylinder Pin.

Install the cylinder pin/ejector rod assembly and loading lever.